# A6.10 Construction Mitigation

A6.10.1 The following is a set of measures that should be incorporated into the specification for the works:

## Site Management

- develop and implement a stakeholder communications plan that includes community engagement before work commences on site;
- develop a Dust Management Plan (DMP);
- display the name and contact details of person(s) accountable for air quality pollutant emissions and dust issues on the site boundary;
- display the head or regional office contact information;
- record and respond to all dust and air quality pollutant emissions complaints;
- make a complaints log available to the local authority when asked;
- carry out regular site inspections to monitor compliance with air quality and dust control procedures, record inspection results, and make an inspection log available to the Local Authority when asked;
- increase the frequency of site inspections by those accountable for dust and air quality pollutant emissions issues when activities with a high potential to produce dust and emissions are being carried out and during prolonged dry or windy conditions;
- record any exceptional incidents that cause dust and air quality pollutant emissions, either on or off the site, and ensure that the action taken to resolve the situation is recorded in the log book; and
- hold regular liaison meetings with other high risk construction sites within 500 m of the site boundary, to ensure plans are co-ordinated and dust and particulate matter emissions are minimised. It is important to understand the interactions of the off-site transport/deliveries which might be using the same strategic road network routes.

## Preparing and Maintaining the Site

- Plan the site layout so that machinery and dust-causing activities are located away from receptors, as far as is possible;
- erect solid screens or barriers around dusty activities or the site boundary that are at least as high as any stockpiles on site;

- fully enclose site or specific operations where there is a high potential for dust production and the site is active for an extensive period;
- install green walls, screens or other green infrastructure to minimise the impact of dust and pollution;
- avoid site runoff of water or mud;
- keep site fencing, barriers and scaffolding clean using wet methods;
- remove materials that have a potential to produce dust from site as soon as possible, unless being re-used on site. If they are being re-used on-site cover as described below;
- cover, seed, or fence stockpiles to prevent wind whipping;
- carry out regular dust soiling checks of buildings within 100 m of site boundary and cleaning to be provided if necessary;
- provide showers and ensure a change of shoes and clothes are required before going off-site to reduce transport of dust;
- put in place real-time dust and air quality pollutant monitoring across the site and ensure they are maintained and the results are checked regularly;
- agree monitoring locations with the Local Authority; and
- where possible, commence baseline monitoring at least three months before phase begins.

## Operating Vehicle/Machinery and Sustainable Travel

- Ensure all on-road vehicles comply with the requirements of the London Low Emission Zone;
- ensure all Non-road Mobile Machinery (NRMM) comply with the standards set within the GLA's Control of Dust and Emissions During Construction and Demolition SPG. This outlines that, from 1st September 2015, all NRMM of net power 37 kW to 560 kW used on the site of a major development in Greater London must meet Stage IIIA of EU Directive 97/68/EC (Directive 97/68/EC of the European Parliament and of the Council, 1997) and its subsequent amendments as a minimum. NRMM used on any site within the Central Activity Zone or Canary Wharf will be required to meet Stage IIIB of the Directive as a minimum. From 1st September 2020 NRMM used on any site within Greater London will be required to meet Stage IIIB of the Directive as a minimum, while NRMM used on any site within the Central Activity Zone or Canary Wharf will be required to meet Stage IV of the Directive as a minimum;
- ensure all vehicles switch off engines when stationary – no idling vehicles;

- avoid the use of diesel- or petrol-powered generators and use mains electricity or battery-powered equipment where practicable;
- impose and signpost a maximum-speed-limit of 10 mph on surfaced haul routes and work areas (if long haul routes are required these speeds may be increased with suitable additional control measures provided, subject to the approval of the nominated undertaker and with the agreement of the Local Authority, where appropriate);
- produce a Construction Logistics Plan to manage the sustainable delivery of goods and materials; and
- implement a Travel Plan that supports and encourages sustainable staff travel (public transport, cycling, walking, and car-sharing).

## Operations

- Only use cutting, grinding or sawing equipment fitted or in conjunction with suitable dust suppression techniques such as water sprays or local extraction, e.g. suitable local exhaust ventilation systems;
- ensure an adequate water supply on the site for effective dust/particulate matter suppression/mitigation, using recycled water where possible and appropriate;
- use enclosed chutes, conveyors and covered skips;
- minimise drop heights from conveyors, loading shovels, hoppers and other loading or handling equipment and use fine water sprays on such equipment wherever appropriate; and
- ensure equipment is readily available on site to clean any dry spillages, and clean up spillages as soon as reasonably practicable after the event using wet cleaning methods.

## Waste Management

- Reuse and recycle waste to reduce dust from waste materials; and
- avoid bonfires and burning of waste materials.

## Measures Specific to Demolition

- Soft strip inside buildings before demolition (retaining walls and windows in the rest of the building where possible, to provide a screen against dust);
- ensure water suppression is used during demolition operations;
- avoid explosive blasting, using appropriate manual or mechanical alternatives; and
- bag and remove any biological debris or damp down such material before demolition.

## Measures Specific to Earthworks

- Re-vegetate earthworks and exposed areas/soil stockpiles to stabilise surfaces as soon as practicable;
- use Hessian, mulches or trackifiers where it is not possible to re-vegetate or cover with topsoil, as soon as practicable; and
- only remove the cover from small areas during work, not all at once.

## Measures Specific to Construction

- Avoid scabbling (roughening of concrete surfaces), if possible;
- ensure sand and other aggregates are stored in bunded areas and are not allowed to dry out, unless this is required for a particular process, in which case ensure that appropriate additional control measures are in place;
- ensure bulk cement and other fine powder materials are delivered in enclosed tankers and stored in silos with suitable emission control systems to prevent escape of material and overfilling during delivery; and
- for smaller supplies of fine powder materials ensure bags are sealed after use and stored appropriately to prevent dust.

## Measures Specific to Trackout

- Regularly use a water-assisted dust sweeper on the access and local roads, as necessary, to remove any material tracked out of the site;
- avoid dry sweeping of large areas;
- ensure vehicles entering and leaving sites are covered to prevent escape of materials during transport;
- inspect on-site haul routes for integrity and instigate necessary repairs to the surface as soon as reasonably practicable;
- record all inspections of haul routes and any subsequent action in a site log book;
- install hard surfaced haul routes, which are regularly damped down with fixed or mobile sprinkler systems or mobile water bowsers, and regularly cleaned;
- implement a wheel washing system (with rumble grids to dislodge accumulated dust and mud prior to leaving the site where reasonably practicable);
- ensure there is an adequate area of hard surfaced road between the wheel wash facility and the site exit, wherever site size and layout permits;
- access gates should be located at least 10 m from receptors, where possible; and

- apply dust suppressants to locations where a large volume of vehicles enter and exit the construction site.